

Using the Lync CX300 Phone

Note: To use your CX300 Lync hard phone, you must be signed-in to the Lync soft phone (or client software) on a Windows computer. Your CX300 will not work if you are on a Macintosh computer.

UNIVERSITY of **HOUSTON**

Information Technology

Contents

The Phone Face.....	3
Answer a Call	4
Make a Call	4
Put a Call on Hold	4
Redial a Number	4
Record Your Voice Mail Greeting	5
Check Your Voice Mail.....	5
Reset Your Voice Mail PIN.....	5

The Phone Face



Answer a Call

To answer a call, choose one of three options:

1. Lift the **Handset**.
2. Press the **Speakerphone** button.
3. Press the **Headset** button.

Make a Call

To make a call, choose one of two options:

1. Dial a **5-digit** campus extension.
2. Dial a **10-digit** off-campus number.

You no longer need to use a 9 to dial off-campus.

Long distance calls require a 1 + a domestic number + your long distance code.

International calls require 011 + an international number + your long distance code.

Put a Call on Hold

To put a call on hold:

1. During a call, press the **Hold** button.

To retrieve a call from hold:

1. Press the **Hold** button.



Redial a Number

To redial a number:

1. Press the **Redial** button.



Record Your Voice Mail Greeting

To record your voice mail greeting:

1. Press and hold the **1** key.
2. Say **Personal Options** into your handset.



Follow the instructions given to you over the phone by the Lync assistant.

Check Your Voice Mail

The Voice Mail indicator light appears red on the **1** key of your phone if you have a message waiting for you.

To check your voice mail:

1. Press and hold the **1** key.
2. Say **Voice Mail** into your handset.
3. Follow the instructions for checking your voice mail.



Note: To use the touchtone menu rather than the voice menu, press **0** after calling your voice mail.

To check your voice mail from another campus phone:

1. Dial **713-743-6111**.
2. Follow the prompts.

To check your voice mail from off-campus:

1. Dial **713-743-6111**.
2. Follow the prompts.

Reset Your Voice Mail PIN

To reset your Voice Mail PIN with Internet Explorer:

1. Go to email.uh.edu.
2. Login to your Email Account.
3. Click on **Options** and click on **Voice Mail**.
4. Click **Reset**.

To reset your Voice Mail PIN with Outlook:

1. Open **Outlook**.
2. Select **Manage Voice Mail** from the **File**.
3. In the Voice Mail Options dialog box, click **Reset PIN**.